


Ceramics Materials Manufacturing

Dr. Alaa Aladdin
2017

Green Body Drying

Drying System

Vapors leach out the binders without causing the part distortion, warping, or cracking that frequently occur in thermal debinding. A Dislocation or carrier gas is circulated through the debinding cell to prevent binder deposit on cold chamber walls.




The vapors are condensed by passing them through a **distillation column** and reused. Solvent and thermal debinding are slow (**10 to over 30 h**) processes, but catalytic debinding is faster and usually takes **2-4 hours** for completion.

Large, bulky parts present considerable difficulty in binder removal and are not good .

QUANTITY OF HOT AIR REQUIRED FOR DRYING PROCESS,

From equation:




where **b** moles of polymer, **P**, react with **n** moles of **O₂** to produce **v** moles of volatile(**g**), **V**, vapor, and **s** moles of solid residue(**s**), **S**, solid ; **ΔH** is the enthalpy of reaction.


Section 6

TYPES OF COMPRESSED AIR for DRYERS

- **Regenerative Type**
- **Single Tower Type**
- **Membrane Type**





REFRIGERANT



COMPRESSED AIR DRYING SYSTEM
DELIQUESCENT DRYER



**SINGLE TOWER
DELIQUESCENT**

TYPES OF DRYERS



Tray dryer

Turbo dryer



Spray dryer

Drum dryer

TYPES OF DRYERS





Figure 9 Batch-continuous air blast freezer with crossflow air circulation.


Tunnel dryer



Screen conveyor dryer



Rotary dryer



Continuous tunnel dryers